

You will need

SHOPPING LIST

- Flower Stencil from Tjhoko Paint
- Stencil of Paris from Tjhoko Paint
- repositionable spray adhesive

TOOLS

- sander
- scraper
- masking tape

PROJECT NOTES

- If the surface still feels oily after sanding it, first seal the entire cupboard with Woodoc Water-Borne Floor Clear Matt before applying the Stencil of Paris; this will prevent the Stencil of Paris from discolouring.
- Seal the cupboard (including the Stencil of Paris) afterwards with Woodoc Water-Borne Floor Clear Matt.

Get started...



1 Remove any sealant or varnish from the wood to create a raw wood look.



2 Spray the back of the stencil with the spray adhesive.




3 Position the stencil and apply the Stencil of Paris with a scraper; wipe off any excess Stencil of Paris as you go along.



4 Remove the stencil carefully, whilst the Stencil of Paris is still wet. Be careful not to smudge it.



5 We used the entire stencil on the bottom left of one door, but for the rest we isolated the pincushion flower by covering the cut-outs next to it. Apply spray



CONTACT AND STOCKISTS Herringbone 021 418 0787, herringbone.co.za Mr Price Home 0800 212 535, mrphome.com Shelly Bergh shellybergh.com Woolworths 0860 022 002, woolworths.co.za